

INSTRUCTIONS FOR INSTALLATION AND USE OF ROOF BRACKETS



WARNING:

FAILURE TO COMPLY WITH THE FOLLOWING INSTRUCTIONS COULD RESULT IN DEATH OR SERIOUS INJURY.

GENERAL REQUIREMENTS

1. Prior to setting up the roof brackets:
 - (a) there must be a plan of action outlining the work to be accomplished, individual responsibilities, personal protective equipment, and a method of communication, and
 - (b) a competent person must determine that the structure can withstand the intended loads.
2. Erect and use in accordance with Local, State, and Federal regulations. Use OSHA compliant fall protection when required.
3. Roof brackets are meant for experienced tradespeople having full knowledge in its use.
4. OSHA Regulations require that employers provide training in the use and care of this product.
5. Do not use this product under the influence of drugs, alcohol, or medication.

CAPACITY

Maximum loading per roof bracket is 250 lbs.

MOUNTING THE ROOF BRACKET

1. Roof Brackets must be securely mounted with three 16-penny (16d) nails through the sheathing into the roof rafter. All nails must be positioned in the top of the nail slots.
2. Maximum horizontal spacing between brackets is 4 feet.
3. Install the appropriate roof brackets so the plank is level or pitched toward the roof surface.
4. Allow two inches of free space above the bracket plank support for unhooking.

INSTALLING THE PLANKING

1. The end of the plank must extend at least 6 inches beyond the roof bracket and no more than 12 inches.
2. Must use 2-inch nominal thickness, scaffold grade planking.

CARE AND MAINTENANCE

1. Inspect brackets before use for deterioration, damage or deformation; discard immediately.
2. Do not weld or otherwise modify roof brackets.